

Working flow

The spot welding H-profile into the clamping equipment → into the main welder
adjust the web height → the side roller of main machine impact → adjust the
welding gun → turn on the switch for feeding welding agent → begin to weld
turn on the switch for withdrawing welding agent → turn off the switch for feeding
welding agent → finish welding → turn off the switch for withdrawing
welding agent



